

# **AMERICAN COATINGS CORPORATION**

Seriving the Environmental Control Industry Since 1979

3037 NW 60th Street Ft. Lauderdale, FL 33309 Toll-Free (800) 533-0151 Fax (954) 970-3690



# No Odor Mastic & Adhesive Remover

100% Organic Industrial Degreaser

AMW-98 is an organic formulation that is perfect to use when you need performance without an odor. AMW-98 is not diluted with water.

AMW-98 is safe to use. AMW-98 meets all specification criteria for no odor products. Additionally, it is ideally suited for projects where odor is a major concern, such as occupied buildings and hospitals.

AMW-98 has been developed to remove cutback asphalt floor adhesives. It can also be used to remove tars, oils and greases. Its special composition has outstanding cleaning capabilities and AMW-98's Flash Point is higher 200°F.

- · Removes cut back adhesives with no odor
- · No Hazardous solvents...No acids
- High Flash Point over 200° F Closed Cup
- · Non-caustic...pH Neutral

# **PROPERTIES**

CLASS	Cleaning Compound
COLOR	Clear
SHIPPING CLASS	55
WEIGHT PER GALLON	6.81 lbs
FLASH POINT (Lowest Component	t) >210° F
BOILING RANGE	460° F - 540° F
PACKAGING	55-Gallon Drums 5-Gallon Pails

#### **APPLICATION SUGGESTIONS - MASTIC REMOVAL**

Consult Material Safety Data before working with this product. Keep Material Safety Data available at all times during usage.

Sample applications are recommended to determine the product's desirability and effective coverage rate.

Always use with adequate mechanical ventilation. Avoid venting any area where chemicals are used into occupied areas or ventilation systems.

## METHOD A:

- Soak material to be removed. Allow sufficient time for AMW-98 to penetrate and loosen the treated material.
- 2. With cleaning tools, such as scrubbers, brooms, brushes or scrapers, remove the treated materials.
- 3. When necessary, repeat the previous steps.
- Thoroughly wash and rinse the treated area with detergent and water. Surface must be totally clean prior to any replacement material installation. Allow adequate time to completely dry.
- Collect and dispose of all materials in accordance with all Federal, State and Local regulations.

### METHOD B:

- Apply an adequate amount of AMW-98 to the material to be removed.
- Begin cleaning operations quickly. Using scrubbers, brooms, brushes or scrapers, work AMW-98 into the treated material and remove it. Continue as required.
- 3. Follow steps 3 through 5 in Method A.